



Tack 2" tube centered on axle end of bar.



Tack joint if adjustable end on centered of frame end of bar.



Starting at frame end of bar tack flatbar centered every 7" every other side all the way down.



Clamping helps to flatten out areas of the flatbar. Do this to other side and weld out with 1" welds.