



Bolt bars into desired length and prep are frame where brackets will land. Then tack brackets into place.



Weld brackets on a minimum of 3 sides, paint, and fully install bars.



Tighten jamnut and all hardware fully. Check all hardware after 100 miles.